

## Programming A Standard Back-Lit Remote To Santel Set-Top-Boxes

### Amino A140, A540, A130

\*Note\* Santel remotes generally come pre-programmed for all oval-shaped Amino boxes.

- 1) Press & Release “STB” button.
- 2) Press & Hold “Setup” button until the “STB” button blinks 3 times (may take 3-5 seconds).
- 3) Press #'s in sequence: **1-8-9-8**.
- 4) Verify Channel +/-, Guide, Menu buttons are working.



### Innovative Systems IS-5112w

- 1) Press & Release “STB” button.
- 2) Press & Hold “Setup” button until the “STB” button blinks 3 times (may take 3-5 seconds).
- 3) Press #'s in sequence: **1-3-7-6**.
- 4) Verify Channel +/-, Guide, Menu buttons are working.



\*Note\* “S.T.B.” sticker may or may not be present or in the spot shown!\*



### Amino Kamai 7X/7B

- 1) Press & Release “STB” button.
- 2) Press & Hold the “Setup” button and the # **7** button at the same time until the STB button blinks twice (may take 3-5 seconds).
- 3) Verify Channel +/-, Guide, Menu buttons are working.

\*NOTE\* Some remotes may have issues programming correctly to this model. Please call our office if issues arise.





## SANTEL REMOTE CONTROL PROGRAMMING

1. Turn on the TV.
2. On the Santel remote control, press & release the “TV” button once; it will blink once.
3. Press and hold “SETUP” until the “TV” button blinks twice (may take a few seconds)
4. Press in sequence: “9” “9” “1”. The TV button will blink twice.
5. Press and release the “CH+” key slowly & continuously. Stop when the TV turns off.
6. Press and release “SETUP” button.

\*TEST POWER (TV ON/OFF) AND VOLUME UP/DOWN!\*

---

### LOCKING REMOTE IN FOR MASTER POWER

(This shuts the power off to the Set-Top-Box & TV at the same time – can only be done after the remote has initially been programmed via the steps above.)

1. Press & release “STB”
2. Press and hold “SETUP” until the “STB” button flashes twice (may take a few seconds)
3. Press in sequence: “9” “9” “5”
4. Press & release the “POWER” button.
5. Press & release the “TV” button.
6. Press & hold “SETUP” until “TV” flashes twice.  
DONE!

**\*\*Make sure you go back to “STB” mode on remote upon finishing for STB functions\*\***

